



Copyright
© Fujitsu Siemens Computers 2008
SAP: 10600985315
FSP: 440000376

Published by
Fujitsu Siemens Computers GmbH
Mies-van-der-Rohe-Straße 8
80807 München, Germany

Contact
www.fujitsu-siemens.com/support

All rights reserved, including intellectual property rights.
Technical data subject to modifications and delivery subject to availability. Any liability that the data and illustrations are complete, actual or correct is excluded. Designations may be trademarks and/or copyrights of the respective manufacturer, the use of which by third parties for their own purposes may infringe the rights of such owner. For further information see http://www.fujitsu-siemens.com/terms_of_use.html



10600985315





AMILO Desktop S Series

First-time setup

English

We make sure




FUJITSU COMPUTERS
SIEMENS





English

AMILO Desktop S Series

Starting up for the first time





Microsoft, MS Windows and Windows Vista are registered trademarks of the Microsoft Corporation.

Adobe Reader is a trademark of Adobe Systems Incorporated.

MultiMediaCard is a registered trademark of Infineon Technologies AG

Sony and Memory Stick are registered trademarks of Sony Electronics, Inc.

All other trademarks referenced are trademarks or registered trademarks of their respective owners, whose protected rights are acknowledged.



Copyright © Fujitsu Siemens Computers GmbH2008

All rights reserved, including rights of translation, reproduction by printing, copying or similar methods, either in part or in whole.

Non-compliance is subject to compensation for damages.

All rights reserved, including rights created by patent grant or registration of a utility model or design.

Subject to availability and technical modifications.







Contents





Innovative technology	1
Further information	1
Operating instructions for the "AMILO Desktop"	1
Notational conventions	1
Important information	3
Connections and Controls	4
Connections	4
Displays and controls	6
Getting started	7
Unpacking and checking the equipment supplied	7
Steps for initial startup	7
Setting up the device	8
Connecting external devices	8
Connecting the cables	8
Disconnecting the cables	8
Connecting the monitor	9
LX300 Wireless Keyboard Set	9
Connecting external devices to the USB ports	13
Connecting the machine to the mains	14
Switching on for the first time: installing the software	14
Switch on the monitor and the machine	14
Installing the software	15
Operation	16
Switch the device on	16
Switching off the device	16
Operational display	17
Memory card reader	18
Inserting the memory card	19
Taking out the memory card	19
Opening and closing the casing for service or system expansion	20
Opening the casing	20
Closing the casing	21
Technical data	21
AMILO Desktop S	21
LX300 Wireless Keyboard Set	22





Contents



Innovative technology

... and ergonomic design make your AMILO Desktop a user-friendly and reliable Desktop PC.

Your machine is equipped with a Microsoft Windows operating system. This is already pre-installed and optimally configured for you. The machine is ready to start immediately when you first switch it on.

Your machine is equipped with the latest technology so that you can fully exploit your computer experience.

- power-saving Intel CPU
- quick WLAN to the b/g/Draft standard, at up to 300 Mbit/s
- very quiet processor fan

With the user-friendly "BIOS Setup Utility" you can control the hardware of your machine and better protect your system against unauthorised access, using the powerful password facilities.

These operating instructions show you amongst other things how to start up and operate your machine.

Further information



General information on your machine can be found in the "AMILO Desktop" operating instructions.

Software-related parts of these instructions refer to Microsoft products, where these are included in the scope of supply of your machine.

When installing other software products, refer to the operating instructions issued by the manufacturer.

Operating instructions for the "AMILO Desktop"

The operating instructions for the "AMILO Desktop" can be found in the Windows Start menu under *All Programs - Fujitsu Siemens Computers* or on the Internet under ["www.fujitsu-siemens.com/support"](http://www.fujitsu-siemens.com/support).

Notational conventions

	Pay particular attention to text marked with this symbol. Failure to observe this warning will endanger your life, will damage the device or lead to loss of data. The warranty will be invalidated if you cause defects in the device through failure to take notice of this warning
	indicates important information that is required to use the device properly.
	indicates an activity that must be performed in the order shown
	indicates a result



Innovative technology

This style	flags data entered using the keyboard in a program dialog or command line, e.g. your password (Name123) or a command to launch a program (start.exe)
This style	refers to information displayed by a program on the screen, e.g.: Installation is completed
<i>This style</i>	is for <ul style="list-style-type: none">• terms and texts in a software user interface, e.g.: Click <i>Save</i>.• names of programs or files, e.g. <i>Windows</i> or <i>setup.exe</i>.
"This style"	is for <ul style="list-style-type: none">• cross-references to another section, e.g. "Safety information"• cross-references to an external source, e.g. a web address: For more information, go to "www.fujitsu-siemens.com"• indicates names of CDs and DVDs as well as names and titles of other materials, e.g.: "CD/DVD Drivers & Utilities" or "Safety" manual
Abc	refers to a key on the keyboard, e.g.: F10
This style	flags concepts and text that are emphasised or highlighted, e.g.: Do not switch off device





Important information




Comply with the safety information in the "Safety" manual and in the operating instructions "AMILO Desktop".










Connections and Controls

This chapter describes the individual hardware components of your machine. It gives you an overview of the displays and connections of the machine. Familiarise yourself with these elements before you start to use the machine.












Connections

Description	Figure	Symbol
PC power supply	 Mains connection	
Sound (external sound sources, e.g. active loudspeaker, microphone) • Sound onboard When an additional sound card is installed, there is no sound function on the motherboard, and "Sound onboard" is not available.	 3.5 mm jack sockets	 Line In  Line Out  Mic




Connections and Controls

Description	Figure	Symbol
Digital sound connection, see also motherboard manual.	 Cinch connection (Coax)	SPDIF Out
Connection for USB devices (e.g. keyboard, mouse IR sender/receiver module, scanner, printer) USB 2.0 Important information on USB 2.0: In order to guarantee a reliable data transfer rate, we recommend that you use a USB connection cable no longer than 3 m.	 USB socket	 or USB
Connection for FireWire or IEEE-1394-compatible devices (e.g. video recorder, digital camera) FireWire	 FireWire socket	1394
Network or DSL modem	 RJ-45 socket	 or LAN
Video input and output connection (optional) (see documentation about the VGA/TV card)	 4-pin or multi-pin socket	SVIDEO IN SVIDEO OUT
Connection for digital video signal (monitor)		DVI
Digital Audio-Video Interface		HDMI



Displays and controls

Description	Symbol	Meaning
On/off switch		Switch for booting up the system. <ul style="list-style-type: none">On/off switch lights up white: The system is switched on.On/off switch flashes yellow: The hard disk is being accessed.On/off switch flashes white: The system is in power-saving mode.



Getting started



Please observe the safety information in the "Important information", Page 3 chapter.

Unpacking and checking the equipment supplied

Keep the original packaging of the equipment in case you need to return it.

- ▶ Remove all the equipment from the packaging.
- ▶ After removal from the packaging, check the equipment for evidence of damage in transport.
- ▶ Check that that the equipment matches the delivery note.
- ↳ If you find damage in transport or a mismatch with the delivery note, inform your sales office without delay!

Steps for initial startup

Only a few steps are required to start up your machine for the first time:

- Select the position for your machine and place it there
- Connect the external devices
- Check the rated voltage and connect the machine to the mains
- Switch on the machine

You can find more details on the individual steps in the following sections.

External devices



If you wish to attach other external devices (such as a printer) to your machine, complete the initial installation of your machine before connecting them. The steps for connecting these external devices are described in the following sections.

Drives and modules



If you wish to fit other drives or modules to your machine, complete the initial installation of your machine before fitting them. The steps for fitting drives and modules are described in the "AMILO Desktop" manual in the chapter "System expansion".



Getting started

Setting up the device



When installing your device, please read the recommendations and safety notes in the "Safety" manual.

Do not place the machine in any position other than the one intended (upright on its feet).

We recommend that you place your device on a surface with good anti-slip qualities. In view of the multitude of different finishes and varnishes used on furniture, it is possible that the rubber feet will mark the surface they stand on.

Do not stack several devices on top of each other.

Do not start the machine in any position other than upright on its feet.

Depending on the location of your machine, it may emit annoying vibration or noises. To avoid this, allow a minimum clearance of 3 mm from other equipment or objects at the sides of the casing where there are no ventilation grilles.

Make sure that the device is adequately ventilated. In order to avoid overheating, do not cover the ventilation area of the monitor or the device.

Do not expose the device to extreme ambient conditions (see "AMILO Desktop S", Page 21, "Ambient conditions"). Protect the device against dust, humidity and heat.

Connecting external devices



Read the documentation on the external device before connecting it.

With the exception of USB devices, always remove all power plugs before connecting external devices!

Do not connect or disconnect cables during a thunderstorm.

Always take hold of the actual plug. Never unplug a cable by pulling the cable itself.

Connect and disconnect the cables in the order described below.

Connecting the cables

- ▶ Turn off all power and equipment switches.
- ▶ Remove all power plugs from the grounded mains outlets.
- ▶ Connect all the cables to the device and the external devices. Please make sure that you always observe the safety notes provided in "Important information", Page 3 .
- ▶ Plug all data communication cables into the appropriate sockets.
- ▶ Plug all power cables into the grounded mains outlets.

Disconnecting the cables

- ▶ Switch off all affected devices.
- ▶ Remove all power plugs from the grounded mains outlets.
- ▶ Unplug all data communication cables from the appropriate sockets.
- ▶ Disconnect all of the cables from the device and from the external devices.



Connecting the monitor

- ▶ Follow the instructions contained in the monitor manual to prepare the monitor for operation (e.g. connecting cables).
- ▶ Plug the data cable into the monitor port of the device.



Depending on the expansion stage of your machine and your monitor, you can also connect the data cable to the DVI interface.

- ▶ Plug the monitor power cable into the grounded mains outlet.

LX300 Wireless Keyboard Set

The LX300 Wireless Keyboard Set with wireless mouse and keyboard is supplied with your machine. Digital radio technology frees you from cumbersome cables.




Comply with the safety information in the safety manual and in the operating instructions for the "AMILO Desktop".

Always use type AAA batteries.

A symbol in the battery compartment shows you which way round to insert the batteries.

Inserting batteries in the mouse



- ▶ Insert the batteries (1).
- ▶ Set the on/off switch on the underside of the mouse to "ON" (2).



Getting started




To save power, set the on/off switch on the underside of the mouse to "OFF" when you are not going to use the mouse for an extended period.

Inserting batteries in the keyboard





A symbol in the battery compartment shows you which way round to insert the batteries.




► Insert the batteries.







Connect the receiver




- ▶ Move the receiver in the direction of the arrow to take it out of the keyboard.





Getting started



- ▶ Plug the receiver into a free USB port on your computer.
- ↳ The radio connection will be established automatically.

Re-establishing the radio connection to the Keyboard Set if required

Normally a radio connection code is generated automatically and the Keyboard Set is then immediately ready for operation. When the connection has successfully been established the LED on the receiver lights up green. The LEDs on the keyboard and mouse light up red if the battery voltage falls below 2.2 V.


If the connection is not established automatically, or if it breaks down, proceed as follows:

- ▶ Unplug the receiver from your computer and plug it in again.
- ▶ Place the mouse at a distance no greater than 30 cm from the receiver.
- ▶ Keep the left mouse button pressed for five seconds.
- ↳ The LED on the receiver will flash green 4 times to indicate that the connection to the mouse has been established successfully.
- ▶ Keep the Esc key on the keyboard pressed for five seconds. `[Esc]`
- ↳ The LED on the receiver will flash green 4 times to indicate that the connection to the keyboard has been established successfully.

Skip forward and back buttons on the mouse

In addition to the right and left mouse buttons and a mouse wheel, your mouse has two additional buttons (1):





These two buttons allow you to skip easily forward and back within an application, e.g. between Internet pages in a Web browser.

Connecting external devices to the USB ports

You can connect a wide range of external devices to the USB ports (e.g. printer, scanner, modem or keyboard).



USB devices are hot-pluggable. This means you can connect and disconnect USB cables while your device is switched on.

Additional information can be found in the documentation for the USB devices.

- ▶ Connect the data cable to the external device.
- ▶ Connect the data cable to one of the USB ports on your device.

Device drivers




The external USB devices you connect to the USB ports usually require no driver of their own, as the required software is already included in the operating system. However, if the external USB device requires its own software, please install it from the data carrier provided with the USB device.

To ensure USB 2.0, the length of the cable used between the front USB port of your device and the external USB device must not exceed 3 m.



Getting started

Connecting the machine to the mains



- ▶ Connect the mains cable to the machine (1).
- ▶ Plug the mains plug into a three-pin socket (2).

Switching on for the first time: installing the software

If the device is integrated into a network, the user and server details as well as the network protocol are required during the software installation.

When you switch on the device for the first time, the supplied software is installed and configured. Plan a reasonable amount of time for this, as this process must not be interrupted.



Once the installation has been started the device must not be switched off, unless the installation has been completed.


During installation, the device may only be rebooted when you are requested to do so!

The installation will otherwise not be carried out correctly and the contents of the hard disk must be completely restored.

Switch on the monitor and the machine

- ▶ Switch on the monitor (see operating instructions for the monitor).





- ▶ Press the on/off button on the front of the machine.
- ↳ The operational display will light up and the machine will start.

Installing the software

- ▶ During installation, follow the on-screen instructions.
- ▶ If anything is unclear regarding the data you are asked to input, read the online Help in your operating system.



Further information on the system, its drivers, utilities and updates can be found on the DVD "Drivers & Utilities" and on the Internet under "<http://www.fujitsu-siemens.com/support>".



Operation

Operation

Switch the device on

- ▶ If necessary, switch the monitor on (see the operating manual for the monitor).
- ▶ Press the ON/OFF switch on the front of the device.
- ↳ The operational display will light up white and the machine will start.

Switching off the device

- ▶ Shut down the operating system properly.
- ▶ If the operating system does not automatically switch the device into power-saving mode or switch it off, press the ON/OFF switch for at least 4 seconds.
- ↳ The device then consumes a minimum amount of energy.




The ON/OFF switch does not fully disconnect the TV from the mains voltage. To completely disconnect the mains voltage, remove the power plug from the power socket.

- ▶ If necessary, switch the monitor off (see the operating manual for the monitor).



Operational display

The operational display appears on the front of the casing.



1 = Operational display



Do not disconnect the machine from the mains whilst in power-saving mode, otherwise data may be lost.


- The display lights up white: The machine is switched on.
- The display flashes white: The machine is in power-saving mode. After switching on at the on/off switch the machine switches on or reverts to the status it was in before power-saving mode was initiated.
- The display flashes yellow: The hard disk is being accessed.
- The display remains unlit: The machine is not connected to the mains or is not ready for operation. If the machine is ready for operation, it can be switched on at the on/off switch.



Operation

Memory card reader

A memory card reader is incorporated in the front of your machine.



Card types that can be read without an adapter:

- Secure Digital Card (SD Card)
- SecureDigital Card HC (SD HC)
- MultiMedia Card (MMC)
- MMC Plus
- MultiMedia Card mobile (MMC mobile)
- Memory Stick (MS)
- Memory Stick Pro

Card types that can be read with an adapter:

- MemoryStick Pro Duo
- Reduced-Size MultiMedia Card (RS-MMC)
- Mini-SecureDigital Card (Mini SD)



Always wait until the data access is completed before removing a card from the slot.




When handling memory cards, comply with the manufacturer's instructions.

Your dealer can supply you with an adapter for your memory card.





Inserting the memory card




- ▶ Carefully insert the memory card into the slot. The memory card contacts must face to the right. Do not force the card in, otherwise the delicate contact surfaces can be damaged.



Taking out the memory card



Always wait until the data access is completed before removing a card from the slot.



- ▶ Carefully take the memory card out of the slot.



Opening and closing the casing for service or system expansion

Opening the casing



Note that various of the components on the motherboard can be still very hot if the machine had been in use a short while previously.

These components can be identified by the following symbol.

- ▶ Switch the machine off. Make sure the machine is off, and not in power-saving mode!




Comply with the safety information in the "Safety" manual and in the operating instructions for the "AMILO Desktop".

Unplug the mains plug from the mains socket.

Don't plug the mains plug back into the mains socket until you have closed the casing up again.


- ▶ Disconnect any cables that make access difficult.



- ▶ Using a cross-head screwdriver (1), unscrew the casing screws.
- ▶ Place the machine on its side as shown.
- ▶ Push the side panel in the direction of the arrow (2).
- ▶ Swing the side panel in the direction of the arrow (3) and lift it off the casing.

Closing the casing

- ▶ Insert the side panel into the guide rail on the base of the casing.



- ▶ Swing the side panel in the direction of the arrow (1).
- ▶ Push the side panel in the direction of the arrow (2) until it clicks home.
- ▶ Using a cross-head screwdriver (3), tighten the casing screws.
- ▶ Reconnect any cables that were disconnected.

Technical data

AMILO Desktop S

Electrical data	
Safety standards complied with:	CE, product safety LVD 2006/95/EC, IEC60950-1, EN60950-1, EMC: 2004/108/EC, EN55022, class B, EN55024, EN61000-3-2/3, RTTE 1999/5/EC, environmental standards: RoHS FSC-03230
Protective rating:	I



Technical data

Electrical data	
Supply voltage range	110 V -240 V
Rated frequency	50 Hz
Dimensions	
Width/depth/height:	108 mm x 355.5 mm x 293.6 mm
Weight	
Basic set-up:	6.9 kg (AMILO Desktop Si 3535)
Ambient conditions	
Climatic category 3K2	DIN IEC 721 part 3-3
Climatic category 2K2	DIN IEC 721 part 3-2
Temperature	
Operation (3K2)	15 °C 35 °C
Transport (2K2)	-25 °C 60 °C
Make sure no condensation is present during operation!	



The data sheet for this machine contains further technical data. The data sheet can be found on the Internet under "www.fujitsu-siemens.com".

LX300 Wireless Keyboard Set

Electrical data - keyboard	
Safety standards complied with:	EN 60950
<ul style="list-style-type: none"> • Power supply • Power consumption: 	<ul style="list-style-type: none"> • 2 x AAA alkali batteries 1.5 V, 2.2 – 3.0 V • Active mode: 8 mA, standby mode: 5 µA
Interface:	USB 2.0 and 1.1 compatible
Frequency band	2.4 GHz
ID codes	8,388,608 IDs (24-bit)
Number of channels	64
Electrical data - mouse	
Safety standards complied with:	EN 60950
<ul style="list-style-type: none"> • Power supply • Power consumption (on white paper) • Resolution (scanning sensitivity) 	<ul style="list-style-type: none"> • 2 x AAA alkali batteries 1.5 V, 2.2 – 3.0 V • Active mode: 25 mA, standby mode: <9 mA • 1000 dpi
Interface:	USB 2.0 and 1.1 compatible
Frequency band	2.4 GHz
ID codes	8,388,608 IDs (24-bit)
Number of channels	64





Technical data

Electrical data - mouse	
Receiver:	
<ul style="list-style-type: none">• Power supply• Power consumption:	<ul style="list-style-type: none">• USB mode: 5 V DC• Active mode: 100 mA
Ambient conditions	
Operating temperature:	0 °C – 40 °C
Range of keyboard / mouse	Up to 10 m (dependent on radio interference in the environment)

